

PRODUCT NAME: _____

PRODUCT MODEL: _____

NAME OF CLIENT: _____

DATE OF PURCHASE: _____

FACTORY CODE: _____

Maintenance record list

DATE IN SERVICE	EQUIPMENT MAINTENANCE DETAIL	MAINTENANCE DATE	MAINTENANCE PERFORMED BY

PRODUCT WARRANTY

- 1.The following are covered by the warranty and can be repaired free of charge:
- (1) A 12-month warranty for the whole machine, batteries, power adapters, and data cables.
- (2) In the case of any malfunction/ breakage/damage that occurs under normal conditions (Non-human damage) within the warranty period, repair will be performed by free.
- (3) The warranty covers problems with the product under normal use. Note: cosmetic issues are not covered by the warranty.
2. The following conditions are not covered under the terms of the warranty. If maintenance services are required, material and service fees may be charged as appropriate:
- (1) Damage caused by transportation, loading and unloading during return, exchange, and repair.
- (2) Any unauthorized modification, disassembly and repair.
- (3) Damage caused by accidental factors or human actions. Such as: liquid ingress, drop damage, input inappropriate voltage, excessive extrusion, motherboard deformation, etc. For the power adapter, if there are obvious hard object damage, cracks, broken feet, severe deformation, damaged wires, broken wires, bare cores, etc.
- (4) Product damage caused by failure to install, use, maintain, and store in accordance with the user manual.
- (5) The warranty certificate does not match the product model or has been altered.
- (6) The product nameplate, SN barcode, and tamper-proof label are torn off or damaged, making them blurred and unrecognizable.
- (7) The product is out of warranty.
- (8) Failure or damage caused by irresistible factors (such as fire, earthquake, flood, etc.).
3. Warranty requires a warranty card as proof.

Repair Service Guide

- (1) Before sending for repair, please back up your personal data in advance. Your personal data may be lost during the maintenance process. We will protect your personal privacy, but we will not be responsible for the damage or loss of personal data during the maintenance process.
- (2) When sending for repair, the product must be professionally inspected by an authorized service center. After confirming the fault, the service center will determine the corresponding maintenance plan. For detected non-faulty products, it will be returned as is.
- (3) If a fee is charged because the product does not meet the warranty conditions, the authorized service center will charge the consumer for maintenance.

Shenzhen Emdoor Information Co., Ltd.

- ☎ Telephone: +86 400-830-4882
- 📍 Address: Emdoor Building, No. 8, Guangke 1st Road, Pingshan District, Shenzhen, Guangdong Province , China
- 📮 Post code: 518122
- ✉ Mail: support@onerugged.com

EQUIPMENT FORM: Rugged Mobile PC

DEVICE MODEL: M195T

SERIAL NUMBER: _____

WARRANTY: _____

INSPECTOR: _____




*The contents of this page shall not be altered without authorization, and please keep the product packaging box to protect your legal rights.

This chapter first tells you step by step how to get the computer up and running. Then, you will find a section briefly introducing the external components of the computer.


OPEN BOX TO CHECK

After unpacking, you should see the following standard items:

· M195T Rugged Mobile PC Terminal · Power Cord · Power Adapter



Note: Use only the power adapter provided with this product. Using other power adapters may damage your device. It must be connected to the AC power supply when it is turned on for the first time.



1. Insert the DC head of the power adapter into the DC port of the device.
2. Plug the female end of the power cord into the power adapter and the male end into the power outlet.
3. The power outlet supplies power to the device through an adapter. Now you can power on the device.

TURNING ON AND OFF THE DEVICE

START UP

1. Press the power button . The operating system Andriod will start.




When you 're work done, you can power it off or leaving it in Sleep or Hibernation mode:


TO ...	DO THIS..
shut down	[Power]→[Shutdown]
reboot	[Power]→[Reboot]
Turn off or wake up the screen	Short press the power button

APPEARANCE INTRODUCTION

Note: 1. Depending on the special model you purchased, the look of the device may be different from the the graphics shown in this manual.




FRONT COMPONENTS



SYMBOL	COMPONENTS	DESCRIPTION
1	Camera	Used to shoot the front pictures

REAR COMPONENTS




SYMBOL	COMPONENTS	DESCRIPTION
1	Camera	Used for photo and video recording
2	Flashlight	Used for lighting
3	NFC	NFC card swipe
4	Taping holes	For fixing straps

LEFT-SIDE COMPONENTS



SYMBOL	COMPONENTS	DESCRIPTION
1	Stereo speakers	Play the device sounds

RIGHT-SIDE COMPONENT




SYMBOL	COMPONENTS	DESCRIPTION
1	Stereo speakers	Play the device sounds
2	Type-c port	Charging port, you can also exchange data through the data line
3	Scan key	The left key for quickly barcodes scan

TOP COMPONENTS



SYMBOL	COMPONENTS	DESCRIPTION
1	Scanning Window	Scan code module
2	Volume- key	Used to decrease the device volume
3	Volume+ key	Used to increase the device volume
4	Power button	Used to sleep, hibernation, wake up, power on and off the device


BOTTOM COMPONENTS



SYMBOL	COMPONENTS	DESCRIPTION
1	Location hole	Used to fix the vehicle mount and docking charger when connecting them.
2	Pogo pin	(Used to connect the base, expand the USB interface, charging port)
3	SIM/TF slot	Used to insert a TF/SIM card

Insert TF card/SIM card

Remove the card holder, then insert a TF card and Micro Sim card.
Put the TF card and Micro SIM card back to their right positions as shown in the figure below, then to use.



Please follow the direction shown in the diagram, sim card notch outward into the card slot

POWER ADAPTER

Notice:

- The power adapter is for your device only. If it is used for other purposes, it may damage the connected electrical appliances or adapters.
- The power cord attached to the power adapter must meet the specifications of the place of purchase. To use this device abroad, consult your dealer for a suitable power cord.
- If you want to unplug the power adapter, you must unplug the power plug on the wall first, and then unplug the power connector plugged into the handset, otherwise the device and adapter will be damaged by external voltage impact.
- When unplugging the plug, please plug in 90° vertically, do not pull the wire, and pull out the plug with your hand.

Since your device runs on DC power, but the power outlet usually provides AC power, the job of the power adapter is to convert the AC power from the power source to the DC power required by the device. The battery is also automatically charged when the power adapter is connected. The adapter input operates from 100V to 240V AC and the output is 19V.

TROUBLESHOOTING

Equipment problems can be caused by hardware, software, or both. When you have a problem, When you encounter any problem, it might be a typical problem that can easily be solved.
This chapter tells you what actions to take when solving common computer problems

PRELIMINARY CHECKLIST

When you encounter a problem, you may wish to do the following preliminary checks first, maybe you can solve the problem at this stage:

- Try to identify the source and category of the problem.
- Make sure you have turned on the power of the peripheral device before turning on the device.
- If there is a problem with the external equipment, please confirm whether the connection of all lines is correct and firm.
- Make sure the settings in the BIOS are completely correct.
- Make sure that all the device drivers are correctly installed.
- Make notes of your observations. Does any message appear on the screen? What is the status of the indicators light? Detailed descriptions are useful to the service personnel when you need to consult one for assistance.

If any problem persists after you follow the instructions in this chapter, contact an authorized dealer for help.